

**Packaging Protocols for
Medical Temperature
Sensitive Products requiring
Storage Temperatures
between 2° C - 8° C
(36° F - 46° F)**

IMPORTANT NOTICE!!


**DD Forms 1502-1 and 1502-2
SHALL NOT BE USED
with these protocols.**

Table of Contents

	Page
Packaging Protocols:	
Endurotherm [®] (ISC) Box Packaging Steps.....	3
Cold Weather Packaging Protocol.....	4
Cold Weather Packaging Protocol Procedures.....	5
Cold Weather Packaging Protocol Diagrams.....	6
Moderate Weather Packaging Protocol.....	10
Moderate Weather Packaging Protocol Procedures.....	11
Moderate Weather Packaging Protocol Diagrams.....	12
Warm Weather Packaging Protocol.....	16
Warm Weather Packaging Protocol Procedures	17
Warm Weather Packaging Protocol Diagrams.....	18
TempTale[®] 4 Procedures:	
TempTale [®] 4	
Starting a TempTale [®] 4.....	22
Reading a TempTale [®] 4.....	23

ISC Endurotherm[®] Box Packing Steps

The packing or layering of the Endurotherm[®] boxes is the same in principle for all four sizes (extra large, large, medium and small).



Cold Weather Packaging Protocol

- Cold Weather Configuration is used when the ambient temperature at the **receiving site** is consistently below 55° F.
- Protocols are designed to keep temperature-sensitive products requiring refrigeration temperatures between 2° C and 8° C (36° F and 46° F) within these temperature ranges during transportation, for up to 72 hours.
- 48 oz. and 24 oz. gel packs are used in all boxes for layering and void space filler.
- Coolant material must be placed in layers according to attached diagrams.
- Cold Weather configurations only use refrigerated gel packs. (See cold weather packing configuration diagrams.)

Cold Weather Packaging Protocol Procedures

The Cold Weather Packaging Protocol is used whenever the ambient or outside temperature at the receiving site consistently remains below 55 degrees Fahrenheit. Begin the cold weather packaging protocol by:

- Placing a layer of refrigerated gel packs at the bottom of the box.
- Next item will be the product.
- Place gel packs around the product's side(s) to fill in gap between product and the insulated walls of the box.
- This is followed by placing an activated TempTale[®] 4 electronic temperature monitor on top of the product. Activate the TempTale[®] 4 temperature monitor by pressing and releasing the "start" button. Once the button is released, a "sunshine" icon will appear in the upper left corner of the LCD. This indicates that the monitor is running. Peel off the tape in the back of the TempTale[®] 4 and place it centered on top of the product.
- Follow with another layer of refrigerated gel packs.
- Above the second layer of refrigerated gel packs insert a fiberboard barrier.
- Add a final layer of refrigerated gel packs above the fiberboard barrier.
- Finally, insert the foam plug to seal the contents of the box.

Notes:

1. Follow procedures according to each protocol diagram of ISC Endurotherm[®] box used.
2. To chill large amounts of gel packs at once, place gel pack boxes inside a refrigerator that has been set to 4° C for at least 30 days prior to use.
3. To quickly chill small amounts of gel packs, place them in a single layer inside a refrigerator as explained above for at least 24 hours prior use.

Extra Large (ISC Box, E-327) – Cold Weather Packaging Protocol Diagram

Box Outer Dimensions:

24" x 24" x 24"

Refrigerant Pack Weight: 81 lbs



See attachment 3 for additional information.

Total amount of chilled Gel Packs = 27

Approximate Weight:

Max load = 145 lbs

Min load = 120 lbs



Large (ISC Box, E-186) – Cold Weather Packing Protocol Diagram

Box Outer Dimensions:

22-1/2" x 19" x 17-1/2"

Refrigerant Pack Weight: 51 lbs

See attachment 3 for additional information.



Total amount of chilled Gel Packs = 17

Approximate Weight:

Max load = 75 lbs

Min load = 50 lbs

View from Top



Medium (ISC Box, E-65) – Cold Weather Packing Protocol Diagram

Box Outer Dimensions: 18" x 12" 18"
Refrigerant Pack Weight: 19-1/2 lbs
See attachment 3 for additional information.



Total amount of chilled Gel Packs = 13

Approximate Weight:

Max load = 40 lbs

Min load = 30 lbs

View from Top



Small (ISC Box E-36-2) – Cold Weather Packing Protocol Diagram

Box Outer Dimensions:

15-1/2" x 12" x 14"

Refrigerant Pack Weight: 12 lbs

See attachment 3 for additional information.

Total amount of

chilled Gel Packs = 8


Approximate Weight:

Max load = 20 lbs



Min load = 15 lbs

View from Top

Top
Layer



Inner
Layer



Side View

Moderate Weather Packaging Protocol

- Moderate Weather Configuration is used when the ambient temperature **at the receiving site** is between 55° F and 77° F.
- Protocols are designed to keep temperature sensitive products requiring refrigeration temperatures between 2° C and 8° C (36° F and 46° F) within these temperature ranges during transportation, for up to 72 hours.
- 48 oz. and 24 oz. gel packs are used in all boxes for layering and void space filler.
- Coolant material must be placed in layers according to attached diagrams. Moderate configuration uses a combination of refrigerated and frozen gel packs. **Frozen gel packs are always farthest away from vaccine.**

Moderate Weather Packaging Protocol Procedures

The Moderate Weather Packing Protocol is used whenever the ambient or outside temperature at the receiving site is between 55 degrees Fahrenheit and 77 degrees Fahrenheit. Begin the Moderate Weather packing protocol by:

- Placing a layer of refrigerated gel packs at the bottom of the box.
- Next item will be the product.
- Place gel packs around the product's side(s) to fill in gap between product and the insulated walls of the box.
- This is followed by placing an activated TempTale[®] 4 electronic temperature monitor on top of the product. Activate the TempTale[®] 4 temperature monitor by pressing and releasing the "start" button. Once the button is released, a "sunshine" icon will appear in the upper left corner of the LCD. This indicates that the monitor is running. Peel off the tape in the back of the TempTale[®] 4 and place it centered on top of the product.
- Follow with another layer of refrigerated gel packs.
- Above the second layer of refrigerated gel packs insert a fiberboard barrier.
- Add a final layer of a combination of refrigerated and frozen gel packs above the fiberboard barrier.
- Finally, insert the foam plug to seal the contents of the box.

Notes:

1. Follow procedures according to each protocol diagram of ISC Endurotherm[®] box used.
2. To chill large amounts of gel packs at once, place gel pack boxes inside a refrigerator that has been set to 4° C for at least 30 days prior to use.
3. To quickly chill small amounts of gel packs, place them in a single layer inside a refrigerator as explained above for at least 24 hours prior use.
4. To freeze large amounts of gel packs at once, place gel pack boxes inside a freezer that has been set to -17°C for at least 30 days prior use.
5. To quickly freeze small amounts of gel packs, place them in a single layer inside a refrigerator as explained above for at least 24 hours prior to use (lay them flat to ensure they maintain their original shape once they are frozen) .

Extra Large (ISC Box, E-327) – Moderate Weather Packaging Protocols Diagram

Box Outer Dimensions: 24" x 24" x 24"
Refrigerant Pack Weight: 81 lbs
See attachment 3 for additional information.

Total amount of Gel Packs:


Chilled = 26

Frozen = 1

Approximate Weight:

Max load = 145 lbs

Min load = 120 lbs



Layer 3:

1 Large Frozen
 & 4 Large
 Refrigerated Gel
 Packs
 (48 oz. each)

**Fiberboard
 Barrier**

Layer 2:

5 Large
 Refrigerated
 Gel Packs
 (48 oz. each)

Use a total
 of 12 Large
 Refrigerated
 Gel Packs
 (6 on each
 long side)
 (48 oz. each)

Layer 1:

5 Large
 Refrigerated
 Gel Packs
 (48 oz. each)

Foam Plug

**Temperature
 Monitor**

Cargo area space in cubic inches is:
(Product)

18" L x 14-1/2" W x 12" H

**Cargo area touches one end only;
 other sides are filled in with Gel packs .**

Side View

Large (ISC Box, E-186) – Moderate Weather Packaging Protocols Diagram

Box Outer Dimensions:

22-1/2" x 19" x 17-1/2"

Refrigerant Pack Weight: 51 lbs*See attachment 3 for additional information.*
Total amount of Gel Packs:




Chilled = 16

Frozen = 1

Approximate Weight:

Max load = 75 lbs

Min load = 50 lbs

View from Top
Top
Layer →Inner
Layer →

Medium (ISC Box, E-65) – Moderate Weather Packaging Protocols Diagram

Box Outer Dimensions: 18" x 12" 18"
Refrigerant Pack Weight: 19-1/2 lbs
See attachment 3 for additional information.

Total amount of Gel Packs = 13

Chilled = 12


Frozen = 1

Approximate Weight:

Max load = 40 lbs

Min load = 30 lbs

View from Top



Layer 3:

1 Medium Frozen Gel Pack
& 2 Medium Refrigerated Gel Packs
(24 oz. each)

Fiberboard Barrier

Layer 2:

3 Medium Refrigerated Gel Packs
(24 oz. each)

Layer 1:

3 Medium Refrigerated Gel Packs
(24 oz. each)

Foam Plug

Temperature Monitor

Cargo area space in cubic inches is:
(Product)

12"L x 6 1/2" W x 6-1/2" H

Cargo area touches one end and one long side only; , other sides are filled in with Gel Packs.

Use a total of 4 Medium Gel Packs (2 in one long side and 2 in one end)
(24 oz. each)

Side View

Small (ISC Box E-36-2) – Moderate Weather Packaging Protocols Diagram

Box Outer Dimensions:

15-1/2" x 12" x 14"

Refrigerant Pack Weight: 12 lbs

See attachment 3 for additional information.

Total amount of Gel Packs = 8

Chilled = 7

Frozen = 1


Approximate Weight:

Max load = 20 lbs


Min load = 15 lbs

View from Top

Top Layer →



Inner Layer →



Layer 3:

1 Medium Frozen Gel Pack & 1 Medium Refrigerated Gel Pack (24 oz. each)

Fiberboard Barrier

Layer 2:

2 Medium Refrigerated Gel Packs (24 oz. each)

Layer 1:

2 Medium Refrigerated Gel Packs (24 oz. each)

Foam Plug

Temperature Monitor

Cargo area space in cubic inches is:

(Product)

10-3/4" L x 6- 1/2" W x 4" H

Cargo area touches the two ends and one long side only, other side is filled in with Gel Packs.

2 Medium Refrigerated Gel Packs in one long side only (24 oz. each).

Side View

Warm Weather Packaging Protocol

- Warm Weather Configuration is used when the ambient temperature **at the receiving site** is consistently above 77° F.
- Protocols are designed to keep temperature sensitive products requiring refrigeration temperatures between 2° C to 8° C (36° F and 46° F) within these temperature ranges during transportation, for up to 72 hours.
- 48 oz. and 24 oz. gel packs are used in all boxes for layering and void space filler.
- Coolant material must be placed in layers according to attached diagrams. Warm weather configuration uses a combination of refrigerated and frozen gel packs. **Frozen gel packs are always farthest away from vaccine.**

Warm Weather Packaging Protocol Procedures

The Warm Weather Packaging Protocol is used whenever the ambient or outside temperature at the receiving site is consistently above 77 degrees Fahrenheit. Begin the warm weather packing protocol by:

- Placing a layer of refrigerated gel packs at the bottom of the box.
- Next item will be the product.
- Place gel packs around the product's side(s) to fill in gap between product and the insulated walls of the box.
- This is followed by placing an activated TempTale[®]4 electronic temperature monitor on top of the product. Activate the TempTale[®]4 temperature monitor by pressing and releasing the "start" button. Once the button is released, a "sunshine" icon will appear in the upper left corner of the LCD. This indicates that the monitor is running. Peel off the tape in the back of the TempTale[®]4 and place it centered on top of the product.
- Follow with another layer(s) of refrigerated gel packs.
- Above the second layer of refrigerated gel packs insert a fiberboard barrier.
- Add a final layer of a combination of refrigerated and frozen gel packs above the fiberboard barrier.
- Finally, insert the foam plug to seal the contents of the box.

Notes:

1. Follow procedures according to each protocol diagram of ISC box used.
2. To chill large amounts of gel packs at once, place gel pack boxes inside a refrigerator that has been set to 4° C for at least 30 days prior to use.
3. To quickly chill small amounts of gel packs, place them in a single layer inside a refrigerator as explained above for at least 24 hours prior use.
4. To freeze large amounts of gel packs at once, place gel pack boxes inside a freezer that has been set to -17°C for at least 30 days prior use.
5. To quickly freeze small amounts of gel packs, place them in a single layer inside a refrigerator as explained above for at least 24 hours prior to use (lay them flat to ensure they maintain their original shape once they are frozen) .

Extra Large (ISC Box, E-327) – Warm Weather Packaging Protocol Diagram

Box Outer Dimensions:

24" x 24" x 24"

Refrigerant Pack Weight: 81 lbs

See attachment 3 for additional information.

Total amount of Gel Packs = 27

Chilled = 25



Frozen = 2

Approximate Weight:

Max load = 145 lbs

Min load = 120 lbs

View from Top



Large (ISC Box, E-186) – Warm Weather Packaging Protocol Diagram

Box Outer Dimensions:

22-1/2" x 19" x 17-1/2"

Refrigerant Pack Weight: 51 lbs

See attachment 3 for additional information.

Total amount of Gel Packs:

Chilled = 15


Frozen = 2

Approximate Weight:

Max load = 75 lbs

Min load = 50 lbs

View from Top

**Layer 3:**

2 Large Frozen
Gel Packs &
2 Large
Refrigerated
Gel Packs
(48 oz. each)

**Fiberboard
Barrier****Layer 2:**

4 Large
Refrigerated
Gel Packs
(48 oz. each)

Layer 1:

4 Large
Refrigerated
Gel Packs
(48 oz. each)

Foam Plug

Temperature
Monitor

Cargo area space in cubic inches is:
(Product)
16-1/2" L x 12" W x 7" H

Cargo area touches one end and one long side only,

Use a total
of 5 Large
Refrigerated
Gel Packs
(2 in one end
and 3 in one
long side)
(48 oz. each)

Medium (ISC Box, E-65) – Warm Weather Packaging Protocol Diagram

Box Outer Dimensions: 18" x 12" x 18"
Refrigerant Pack Weight: 19-1/2 lbs
See attachment 3 for additional information.

Total amount of Gel Packs = 13

Chilled = 11


Frozen = 2

Approximate Weight:

Max load = 40 lbs


Min load = 30 lbs

View from Top



Foam Plug

Fiberboard Barrier



Small (ISC Box E-36-2) – Warm Weather Packing Protocol Diagram

Box Outer Dimensions:

15-1/2" x 12" x 14"

Refrigerant Pack Weight: 12 lbs*See attachment 3 for additional information.*
Total amount of Gel
Packs = 8



Chilled = 6

Frozen = 2

Approximate Weight:

Max load = 20 lbs

Min load = 15 lbs




Starting a TempTale[®]4 Monitor

Hold down the **start** button (**the green button on the monitor**) until you see the sunshine icon (picture) on the upper left corner of the LCD that confirms that the monitor has started.

When the monitor is activated, the sunshine icon will stay on until the monitor has been stopped.

The monitor will begin recording data after the startup delay is completed.



Instructions for Reading a TempTale[®]4 LCD

Press the **start** button. Five pieces of information will scroll, always in this order:

- Average temperature during the entire recording cycle
- Highest Temperature reached during the recording cycle
- Cumulative amount of time above the high temperature alarm
- Lowest Temperature reached during the recording cycle
- Cumulative amount of time below the low temperature alarm

